Dynamix UM-SE

G.SHDSL.bis EFM Network Extender

User Manual

Version 0.03

TABLE OF CONTENTS

1 INTRODUCTION 5

1.1 DESCRIPTIONS 5
1.2 FEATURES 6
1.3 SPECIFICATIONS 6
1.4 APPLICATIONS 8

2 GETTING TO KNOW ABOUT THE EFM MODEM 9

2.1 FRONT PANEL 9
2.2 REAR PANEL 11
2.2.1 WAN Port 11
2.2.2 LAN ports and MGMT port 12
2.2.3 Console Port 12
2.2.4 Power connection 13
2.2.5 Reset Button 13
2.2.6 Protective Earth (Frame Ground) terminal 13

3 CONFIGURATION USE WEB BROWSER 14

3.1 CONFIGURATION METHOD 14
3.1.1 Web configuration 14
3.1.2 Serial console configuration 14
3.1.3 Telnet configuration 14
3.2 INSTALLATION 15
3.3 SETUP UP ON WEB BROWSER 16
3.4 BASIC SETUP 17
3.4.1 Operation mode and MGMT 19
3.4.2 DHCP server 20
3.4.3 LAN 22
3.4.4 Review 23
3.5 ADVANCED SETUP 24
3.5.1 SHDSL.bis EFM 24
3.5.1.1 Line Type 25
3.5.1.2 Annex Type 25
3.5.1.3 TCPAM Type 25
3.5.1.4 Main Rate 25
3.5.1.5 SNR margin 25
3.5.1.6 Line Probe 26
3.5.2 VLAN 27
3.5.2.1 802.1Q Tag-Based VLAN 29
3.5.2.2 Port-Based VLAN 32
3.5.2.3 Port-based QinQ 34

3.5.3 QoS 36
3.5.3.1 Port Based Priority 37
3.5.3.2 VLAN Tag Priority 39
3.5.3.3 IP DSCP Priority 42
3.5.4 Rate Control 45
3.6 STATUS 46
3.6.1 SHDSL .Bis EFM 46
3.6.2 MGMT 48
3.6.3 LAN 49
3.6.4 Interface 50
3.7 ADMINISTRATION 51
3.7.1 Security 51
3.7.2 SNMP 54
3.7.2.1 Community Pool 55
3.7.2.2 Trap Host Pool 55
3.8 UTILITY 57
3.8.1 System Info 58
3.8.2 Config Tool 59
3.8.3 Upgrade 60
3.8.4 Logout 60
3.8.5 Restart 61
4 CONFIGURATION USE SERIAL CONSOLE AND TELNET WITH MENU DRIVEN INTERFACE 63
4.1 INTRODUCTION 63
4.1.1 Login to the Console Interface 63
4.1.2 Telnet login 63
4.1.3 Menu Driven Interface Commands 64
4.1.4 Window structure 65
4.2 MAIN MENU TREE 65
4.2.1 Menu tree for authorized user 66
4.2.2 Menu tree for unauthorized user 67
4.3 ENABLE 68
4.4 SETUP 70
4.4.1 SHDSL.bis 70
4.4.1.1 Mode 70
4.4.1.2 Link 70
4.4.1.3 Annex 71
4.4.1.4 TCPAM 71
4.4.1.5 Maximum main rate 71
4.4.1.6 SNR Margin 71
4.4.1.7 Line Probe 71
4.4.1.8 Clear 71

4.4.2 LAN *73*
4.4.3 VLAN *74*
4.4.3.1 Mode 74
4.4.3.2 802.11Q VLAN 75
4.4.3.3 Port Based VLAN 76
4.4.4 QoS *78*
4.4.4.1 Mode 78
4.4.4.2 Queue weight 78
4.4.4.3 Queue schedule 79
4.4.4.4 Port Based Priority QoS 80
4.4.4.5 VLAN Tag Priority QoS 81
4.4.4.6 IP DSCP Priority Qos 82
4.4.4.7 List 82
4.4.5 RATE *83*
4.4.6 MGMT *83*
4.4.7 DHCP *84*
4.4.7.1 DHCP Server 84
4.4.7.2 DHCP fixed Host 85
4.4.8 DNS proxy *86*
4.4.9 Host name *86*
4.4.10 Default *87*
4.5 STATUS 87
4.5.1 Shdsl.bis *88*
4.5.2 Interface *88*
4.6 SHOW 89
4.7 WRITE 89
4.8 REBOOT 90
4.9 PING 90
4.10 ADMINISTRATION 91
4.10.1 User Profile *91*
4.10.2 Security *92*
4.10.2.1 Telnet TCP port 92
4.10.2.2 IP address pool 93
4.10.3 SNMP *94*
4.10.3.1 Community 94
4.10.3.2 Trap host 95
4.10.4 Supervisor Password and ID *96*
4.10.4.1 Supervisor Password 96
4.10.4.2 Supervisor ID 96
4.11 UTILITY 97
4.11.1 Upgrade main software *98*
4.11.2 Backup system configuration *98*

4.11.3 Restore system configuration 98

4.12 EXIT 99

5 APPENDIX – SETUP TABLE 100

1 Introduction

1.1 Descriptions

The EFM Based Network Extender (or say EFM Bridge Modem) which provides a flexible and friendly solution for the Ethernet based services provision to subscribers by the service provider. Additionally, this family of products provides a simple way in a back-to-back deployment to provide point to point configuration. This allows broadband service providers to deploy single DSL lines economically when required for low density geographical areas or during start up phase.

EFM Network Extender provides cost-effectively symmetrical bandwidth at rates up to 22.8 Mbps (for 4-pairs model) which allows service providers to deliver friendly Ethernet services rapidly. EFM Network Extender extends the reach of Ethernet services to the sites with no fiber access to by using bonded copper pairs. Designed with standard-based EFM technology (2BASE-TL), the delivery of Ethernet services with EFM modem can be deployed quickly on the existing copper plant. It is a nice application for back-to-back connection between remote office and enterprise headquarters.

EFM Network Extender implements the management features based on IEEE 802.3ah standard and it enables users to significantly reduce operation expense by eliminating unnecessary transformation between Ethernet and legacy ATM network. As based on user-friendly Ethernet, it saves time and costs because of simple engineering task without additional trainings costs. Packet based technology which architecture utilizes 100% packet transmission technology for optimum throughput and reliability. With a compact form-factor design and optimization for the use over existing copper network, EFM Network Extender reduces the initial investment cost and deployment time in delivering higher speed Ethernet service. It provides minimized risk bearing and quick return on investment to service providers and enterprises

EFM Network Extender can bond up to 4 pairs and deliver up to 22.8 Mbps Ethernet services to all users within their service area by utilizing existing copper infrastructure and EFM 802.3ah PAF bonding technology. Service Providers and enterprises are able to offer symmetrical high speed connectivity for transparent Ethernet service on DSLAM backhaul or Wireless backhaul and more.

EFM Network Extender provides future-proof features meeting Ethernet Quality of Service (QoS) requirements by utilizing 802.1q VLAN capabilities, four levels of priorities, traffic flow control and rate control. This traffic management and QoS features enable service providers to offer highly profitable and value-added services to a vast majority of business and institutional sites.

1.2 Features

- **Extending Ethernet Services to sites with existing copper infrastructure**
- **Increased Flexibility in Deployment**
- **Lower Investment and Quick Return on Investment**
- **EFM Bonding (PAF, PME Aggregation Function) up to 22.8Mbps (4 pairs)**
- **Support EFM OAM complying IEEE 802.3ah**
- **Flexible configuration as CPE side or CO side**
- **Low Delay, Jitter and Packet Loss for delay sensitive application**
- **Comprehensive and easy OAM & P functions in provisioning and managing**
- **QoS feature for guaranteed Ethernet service**
- **Future-proof Ethernet traffic management and QoS features**

1.3 Specifications

WAN Interface

One RJ45 Connector, 8 pins

SHDSL.bis: ITU-T G.991.2 (2004) Annex AF/BG

Encoding scheme: 16-TCPAM, 32-TCPAM

2BASE-TL, 64/65-octet encoding

EFM bonding (IEEE 802.3ah PAF)

Maximum date rate is 22.8Mbps for 8-wire mode (5.7Mbps/Port x 4Ports=22.8Mbps)

Impedance: 135 ohms

LAN Interface

Four RJ45 Connectors

4-ports switching hub

10/100 Base-T auto-sensing and auto-negotiation

Auto-MDI/MDIX (Auto-Crossover)

802.1d Transparent Bridging

Up to 2K MAC Address

Indicators

WAN1, WAN2, WAN3 and WAN4: Link/Activity

LAN1, LAN2, LAN3 and LAN4: Link/Act and 10M/100Mbps

System: Power, Alarm and Management port

VLAN Support

802.1Q Tag-Based VLAN

Port-Based VLAN

Port-Based Q-in-Q

Priority Re-mapping

VLAN Trunk mode

QoS Support

Ingress Rate control

Egress Traffic shaping

Classification based on Port Base / VLAN Tag / DSCP

4 Priority Queues

WRR(Weighted round-robin)/ BE(Best Effort) / SP(Strictly Priority)

Management Interface

In-Band

EFM (IEEE 802.3ah) OAM

Web Browser (HTTP) , Telnet, Console

Out-Band

Easy-to-use web-based GUI for quick setup, configuration and management

Menu-driven interface for local console and Telnet access

Password protected management and access control list for administration

Software upgrade via web-browser or FTP server

Physical/Electrical

Dimensions: 19.8 x 4.8 x 16.6cm (WxHxD)

Power: 100~240VAC (use external power adapter)

Power consumption: 9 watts max.

Temperature: 0~45˚C

Humidity: 0%~95%RH (non-condensing)

Memory

2MB Flash Memory, 8MB SDRAM

Products' Information

Dynamix UM-SE/1 pair 2BASE-TL EFM Network Extender

Dynamix UM-SE/2 pair 2BASE-TL EFM Network Extender

Dynamix UM-SE/4 pair 2BASE-TL EFM Network Extender

1.4 Applications



EFM DSLAM to point connection



Point to point connection

2 Getting to know about the EFM Modem

This section will introduce hardware of the EFM modem.

2.1 Front Panel

The front panel contains LED which show status of the EFM Modem.



LED status of EFM Modem :

LEDs		Active	Description
PWR		On	Power on
ALM		On	SHDSL.bis line connection is dropped
		Blink	SHDSL.bis self test
MGMT		On	Management port line connection is established
WAN	LINK 1	On	SHDSL.bis line 1 connection is established
		Blink	SHDSL.bis line 1 handshake Transmit or received data over SHDSL.bis link 1
	LINK 2	On	SHDSL.bis line 2 connection is established
		Blink	SHDSL.bis line 2 handshake Transmit or received data over SHDSL.bis link 2
	LINK 3	On	SHDSL.bis line 3 connection is established
		Blink	SHDSL.bis line 3 handshake Transmit or received data over SHDSL.bis link 3
	LINK 4	On	SHDSL.bis line 4 connection is established
		Blink	SHDSL.bis line 4 handshake Transmit or received data over SHDSL.bis link 4
LAN	LINK/ACT1	On	Ethernet cable is connected to LAN 1
		Blink	Transmit or received data over LAN 1
	LINK/ACT2	On	Ethernet cable is connected to LAN 2
		Blink	Transmit or received data over LAN 2
	LINK/ACT3	On	Ethernet cable is connected to LAN 3
		Blink	Transmit or received data over LAN 3
	LINK/ACT4	On	Ethernet cable is connected to LAN 4
		Blink	Transmit or received data over LAN 4
LAN	100M 1	On	LAN 1 is on 100M mode
		Off	LAN 1 is on 10M mode
	100M 2	On	LAN 2 is on 100M mode
		Off	LAN 2 is on 10M mode
	100M 3	On	LAN 3 is on 100M mode
		Off	LAN 3 is on 10M mode
	100M 4	On	LAN 4 is on 100M mode
		Off	LAN 4 is on 10M mode

2.2 Rear Panel

The rear panel of G.SHDSL.bis EFM Modem is where all of the connections are made.



Connector	Description
DC-IN	Power adaptor inlet: Input voltage 9VDC
CONSOLE	RJ-45 for system configuration and maintenance
RST	Reset button for reboot or load factory default
LAN (1,2,3,4)	10/100BaseT auto-sensing and auto-MDIX for LAN port (RJ-45)
MGMT	RJ-45 for management port
DSL	G.SHDSL .Bis interface for WAN port (RJ-45)
⏚	Frame Ground / Protective earth

2.2.1 WAN Port

The EFM modem have one port for WAN port connection, this is a G.SHDSL .Bis interface

The pin assignments for SHDSL line cable are:



For one pair (2-wire) model, Loop1 has been used

For two pair (4-wire) model, Loop1 and 2 have been used

For four pair (8-wire) model, Loop1, 2, 3 and 4 have been used

2.2.2 LAN ports and MGMT port

The EFM modem have four LAN ports and one MGMT Ethernet port. Those ports are auto-negotiating, auto-crossover. In 10/100Mbps Fast Ethernet, the speed can be 10Mbps or 100Mbps and the duplex mode can be half duplex or duplex.

An auto-negotiating port can detect and adjust to the optimum Ethernet speed(10/100 Mbps) and duplex mode(full duplex or half duplex) of the connected device.

An auto-crossover(auto-MDI/MDI-X) port automatically works with a straight-through or crossover Ethernet cable.

2.2.3 Console Port

Connect the RJ-45 jack of the console cable to the console port of the EFM modem. Connect the DB-9 female end to a serial port(COM1 , COM2 or other COM port) of your computer.

The wiring diagram of console cable is as following:



The pin assignment of RJ-45 modular jack on the console cable:

Pin Number	Abbrev.	Description	Figure
1	DSR	DCE ready	
2	DCD	Received Line Signal Detector	
3	DTR	DTE ready	
4	GND	Signal Ground	
5	RXD	Received Data	
6	TXD	Transmitted Data	
7	CTS	Clear to Send	
8	RTS	Request to Send	

2.2.4 Power connection

Make sure you are using the correct power source as the AC/DC adaptor. Inset the female end of power adaptor's cord into the power receptacle on the rear panel. Connect the power adaptor to an appropriate power source.

2.2.5 Reset Button

The reset button can be used only in one of two ways.

(1) Press the Reset Button for two second will cause system reboot.

(2) Pressing the Reset Button for eight seconds will cause the product loading the factory default setting and losing all of yours configuration. When you want to change its configuration but forget the user name or password, or if the product is having problems connecting to the Internet and you want to configure it again clearing all configurations, press the Reset Button for eight seconds with a paper clip or sharp pencil.

2.2.6 Protective Earth (Frame Ground) terminal

The marked lug or terminal should be connected to the building protective earth bus.

The function of protective earth does not serve the purpose of providing protection against electrical shock, but instead enhances surge suppression on the DSL lines for installations where suitable bonding facilities exist.

The connector type is M3 machine screw.

3 Configuration use Web Browser

3.1 Configuration method

There are three methods to configure the EFM modem: serial console, Telnet and Web Browser. Users have to choose one method to configure the EFM modem.

3.1.1 Web configuration

Make sure that Ethernet Adapter had been installed in PC or NB used for configuration of the modem. TCP/IP protocol is necessary for web configuration, so please check the TCP/IP protocol whether it has been installed.
The EFM modem provides a browser interface that lets you configure and manage the EFM modem. After you set up your IP address for the EFM modem. You can access the EFM modem's Web interface applications directly in your browser by entering the IP address of the EFM modem.You can then use your Web browser to list and manage configuration parameters from PC.
Web Configuration requires Internet Explorer 5.0 or later or Netscape Navigator 6.0 and later versions. The recommended screen resolution is 1024 by 768 pixels.

3.1.2 Serial console configuration

For Serial Console, users can directly connecting a terminal or a PC equipped with a terminal-emulation program (such as Hyper Terminal) to the EFM modem's serial console port. Use the supplied serial cable (RJ-45 to DB9F) is required to connect the EFM modem to PC. After marking this connection, configure the terminal-emulation program to use the following parameters: 9600 bps , 8 data bits , no parity and 1 stop bit.

3.1.3 Telnet configuration

Make sure that Ethernet Adapter had been installed in PC or NB used for configuration of the modem. The EFM modem also supports telnet for remote configuration. The command is "telnet 192.168.1.1" . It with asks for user name and password for remote login when using telnet, please use "admin" for username and "admin" for password. All display screen are as same as serial console configuration.
The IP address 192.168.1.1 is the default vaule and you can change to another one for you application.

3.2 Installation

This following guide is designed to lead users through Web Configuration of G.shdsl.bis EFM Modem in the easiest and quickest way possible. Please follow the instructions carefully.

Connect the power adapter to the port labeled DC 9V on the rear panel of the EFM modem.

Connect the Ethernet cable to MGMT port.

(Note: The EFM modem supported auto-MDIX switching hub so both straight through and cross-over Ethernet cable can be used.)

Connect the phone cable to the EFM modem and the other side of phone cable to wall jack.

Connect the power adapter to power source.

Turn on the PC or NB, which is used for configuration the EFM modem.

To avoid possible damage to this EFM modem, do not turn on the EFM modem before Hardware Installation.



Connection with SHDSL .Bis EFM Modem

3.3 Setup up on Web Browser

This section introduces the configuration and functions of the web-based management.

It is an HTML-based management interface that allows easy EFM modem setup and management.

The EFM modem offers all monitoring and management features that allow users to manage this EFM modem form anywhere on the network through a standard browser such as Internet Explorer.

TCP/IP setup

When DHCP function is Enable, the EFM modem acts as DHCP server in your network, the EFM modem will automatically assign IP address for PC for management port connection.

For Window System, click the start button. Select setting and control panel.

Double click the network icon.

In the Configuration window, select the TCP/IP protocol line that has been associated with your network card and then click property icon.

Choose IP address tab and select Obtain IP address automatically and then Click OK button.

System Login

User can use browser program such as Internet Explorer on your PC to connect the EFM Modem. Type "http://" and the IP address like as "http://192.168.1.1".

The default IP address and sub net-mask of the management port of EFM Modem are 192.168.1.1 and 255.255.255.0.

If DHCP function is Disable, your PC can set the same net-mask such as 192.168.1.X which X is from 2 to 254, that are also can connect.

Type User Name root and Password root and then click OK.

The default user name and password both is *root*. For the system security, suggest changing them after configuration.

Note: For safety purpose, the password will be prompt as star symbol.

Note: After changing the User Name and Password, strongly recommend you to save them because another time when you login, the User Name and Password have to be used the new one you changed.

Following is the first screen that displays when you access the web configurator.

3.4 Basic Setup

The Basic Setup contains:

- **Operation mode and MGMT port IP**
- **DHCP server**
- **LAN**

User can use it to completely basic setup the EFM modem.

Below diagram is showed as Basic Setup's flowchart.



3.4.1 Operation mode and MGMT

Click Basic for basic installation.

Click CPE (Customer Premises Equipment) side or CO (Central Office) side to setup the operation mode. When connection with EFM DSLAM, the SHDSL.bis EFM modem's working mode is CPE. When "LAN to LAN" connection, one side must be CO and the other side must be CPE.

Enter Parameters in MGMT item.
The EFM modem needs an IP address for it to be managed over the network. The factory default IP address is 192.168.1.1. The subnet mask specifies the network number portion of an IP address. The factory default subnet mask is 255.255.255.0 . You can configure another IP address in a different Subnet Mask for management purposes.

IP: 192.168.1.1
Subnet Mask: 255.255.255.0
Host Name: SOHO

Some of the ISP requires the Host Name as identification. You may check with ISP to see if your Internet service has been configured with a host name. In most cases, this field can be ignored.
And than click Trigger DHCP service is Disable or Server. If you don't need the DHCP service, please click Disable.

3.4.2 DHCP server

Press Next to set the next page:

Dynamic Host Configuration Protocol (DHCP) is a communication protocol that lets network administrators to manage centrally and automate the assignment of Internet Protocol (IP) addresses in an organization's network. Using the Internet Protocol, each machine that can connect to the Internet needs a unique IP address. When an organization sets up its computer users with a connection to the Internet, an IP address must be assigned to each machine.

Without DHCP, the IP address must be entered manually at each computer. If computers move to another location in another part of the network, a new IP address must be entered. DHCP lets a network administrator to supervise and distribute IP addresses from a central point and automatically sends a new IP address when a computer is plugged into a different place in the network.

The embedded DHCP server assigns network configuration information at most 253 users accessing the Internet in the same time.

For example: If the LAN IP address is 192.168.0.1, the IP range of LAN is 192.168.0.2 to 192.168.0.254. The DHCP server assigns the IP form Start IP Address to End IP Address. The legal IP address range is form 0 to 255, but 0 are reserved as network name and 255 are reserved for broadcast. It implies the legal IP address range is from 1 to 254. That means you cannot assign an IP greater than 254 or less than 1.

Lease time 72 hours indicates that the DHCP server will reassign IP information in every 72 hours.
The default value is 72 hours .You can set up from 1 to 720 hours according to your application.

Moreover, you may assign a fixed IP address to some device while using DHCP, you have to put this device's MAC address in the Table of Fixed DHCP Host Entries.

3.4.3 LAN

Press Next to set the next page:

Enter Parameters in LAN:

LAN type item can been selected as: Disable, Dynamic IP and Static IP.

If you select Disable and Dynamic IP, can't need input all IP address etc.

If you select Static IP, you can enter the following: IP, Subnet Mask, Gateway and DNS Server's IP.

You must type the dotted decimal notation for DNS Server's IP address

The default values are as following:

IP Address: 192.168.2.1

Subnet Mask: 255.255.255.0

Gateway: 0.0.0.0

DNS Server 1: 168.95.1.1

DNS Server 2: 168.95.192.1

DNS Server 3:

3.4.4 Review

Press Next to set the next page:

The screen will prompt the new configured parameters. Checking the parameters and Click Restart The EFM modem will reboot and working with new parameters or press or Continue to configure another parameters.

3.5 Advanced Setup

Note: The advanced functions are only for advanced users to setup advanced functions. The incorrect setting of advanced function will affect the performance or system error, even disconnection.

Advanced setup contains SHDSL.bis EFM, VLAN, QoS and Rate Control parameters.

3.5.1 SHDSL.bis EFM

You can setup the Link (number of wires), Annex type, TCPAM type, Main Rate, Sub Rate and SNR margin for SHDSL.bis EFM parameters.

Click SHDSL.bis EFM

3.5.1.1 Line Type

Line type means how many wire you want to use on SHDSL.bis connection.

Line Type / EFM Modem	2-wire	4-wire	8-wire
2-wire model	●		
4-wire model	●	●	
8-wire model	●	●	●

For example, 8-wire model can select 2-wire, 4-wire or 8-wire line type.

3.5.1.2 Annex Type

There are two Annex types: Annex AF and Annex BG in SHDSL.bis . Check with your ISP about it.

3.5.1.3 TCPAM Type

The default option is Auto. You may assign the different type manually by click the caption TPCAM-16 or TPCAM-32 .

3.5.1.4 Main Rate

You can setup the SHDSL.bis main rate is in the multiple of 64kbps , 128kpbs or 256 kpbs according using which model.

Main Rate (Unit: kbps)

SHDSL.bis EFM Modem	multiple	TCPAM-16	TCPAM-32
		N=3~60	N=12~89
2-wire model	64	192 ~ 3840	768 ~ 5696
4-wire model	128	384 ~ 7680	1536 ~ 11392
8-wire model	256	768 ~ 15360	3072 ~ 22784

3.5.1.5 SNR margin

SNR margin is an index of line connection quality. You can see the actual SNR margin in STATUS SHDSL.bis. The larger is SNR margin; the better is line connection quality.

For example, if you set SNR margin in the field as 5, the SHDSL.bis connection will drop and reconnect when the SNR margin is lower than 5. On the other hand, the device will reduce the line rate and reconnect for better line connection quality.
The range of SNR margin setting are -10 to 21.

3.5.1.6 Line Probe

For adaptive mode, you can setup the Line Prodbe is Enable. The EFM modem will adapt the data rate according to the line status. Otherwise, setup to Disbale.

The screen will prompt the parameters that will be written in NVRAM. Check the parameters before writing in NVRAM.

Press Restart to restart the EFM modem working with new parameters or press continue to setup another parameter.

3.5.2 VLAN

Click VLAN to configure VLAN.

VLAN (Virtual Local Area Network) allows a physical network to be partitioned into multiple logical networks. Devices on a logical network belong to one group. A device can belong to more than one group. With VLAN, a device cannot directly talk to or hear from devices that are not in the same group.

With MTU (Multi-Tenant Unit) applications, VLAN is vital in providing isolation and security among the subscribers. When properly configured, VLAN prevents one subscriber from accessing the network resources of another on the same LAN.

VLAN also increases network performance by limiting broadcasts to a smaller and more manageable logical broadcast domain. In traditional switched environments, all broadcast packets go to each every individual port. With VLAN, all broadcasts are confined to a specific broadcast domain.

User can choose two types of VLAN: 802.1Q Tag-Based VLAN and Port-Based VLAN.

The VLAN Setup screen changes depending on whether you choose 802.1Q Tag-Based VLAN type or Port Based VLAN type in this screen.

The IEEE 802.1Q defines the operation of VLAN bridges that permit the definition, operation, and administration of VLAN topologies within a bridged LAN infrastructure.


VID 20
WAN4
WAN5
WAN3
VID 10
WAN6
VID 30
WAN2
WAN7
WAN8
WAN1
Backbone
G.SHDSL .Bis
EFM Modem
LAN1
LAN2
LAN3
LAN4
VID 10
VID 20
VID 30

3.5.2.1 802.1Q Tag-Based VLAN

Click the 802.1Q Tag-Based VLAN to configure the EFM modem.

VID: (Virtual LAN ID) It is an definite number of ID which number is from 1 to 4094.

PVID: (Port VID) It is an untagged member from 1 to 4094 of default VLAN.

Link Type: Access means the port can receive or send untagged packets.

Trunk means that the prot can receive or send tagged packets.



TCI (Tag Control Information field) including user priority, Canonical format indicator(CFI) and VLAN ID.

TPID- defined value of 8100 in hex. When a frame has the EtherType equal to 8100, this frame carries the tag IEEE 802.1Q / 802.1P.

User Priority- Defines user priority, giving eight (2^3 = 8) priority levels. IEEE 802.1P defines the operation for these 3 user priority bits.(Refer to following table)

CFI(Canonical Format Indicator) is always set to zero for Ethernet switches. CFI is used for compatibility reason between Ethernet type network and Token Ring type network. If a frame received at an Ethernet port has a CFI set to 1, then that frame should not be forwarded as it is to an untagged port.

VID- VLAN ID is the identification of the VLAN, which is basically used by the standard 802.1Q. It has 12 bits and allow the identification of 4096 (2^{12}) VLANs. Of the 4096 possible VIDs, a VID of 0 is used to identify priority frames and value 4095 (FFF) is reserved, so the maximum possible VLAN configurations are 4,094.

The EFM modem initially default configures one VLAN, VID=1.

A port such as LAN1 to 4, DSL or sniffing can have only one PVID, but can have as many VID as the EFM modem has memory in its VLAN table to store them.

Ports in the same VLAN group share the same frame broadcast domin thus increase network performance through reduced boardcast traffic. VLAN groups can be modified at any time by adding, moving or changing ports without any re-cabling.



Before enabling VLANs for the EFM modem, you must first assign each port to the VLAN group(s) in which it will participate. By default all ports are assigned to VLAN1 as untagged

ports. Add a port as a tagged port if you want it to carry traffic for one or more VLANs, and any intermediate network devices or the host at the other end of the connection supports VLANs. Then assign ports on the other VLAN-aware network devices along the path that will carry this traffic to the same VLAN(s), either manually or dynamically using GVRP. However, if you want a port on this EFM modem to participate in one or more VLANs, but none of the intermediate network devices nor the host at the other end of the connection supports VLANs, then you should add this port to the VLAN as an untagged port.

Note: VLAN-tagged frames can pass through VLAN-aware or VLAN-unaware network Inter-connection devices, but the VLAN tags should be stripped off before passing it on to any end-node host that does not support VLAN tagging.

VLAN Classification – When the EFM modem receives a frame, it classifies the frame in one of two ways. If the frame is untagged, the EFM modem assigns the frame to an associated VLAN (based on the default VLAN ID of the receiving port). But if the frame is tagged, the EFM modem uses the tagged VLAN ID to identify the port broadcast domain of the frame.

Port Overlapping – Port overlapping can be used to allow access to commonly shared network resources among different VLAN groups, such as file servers or printers.

Untagged VLANs – Untagged (or static) VLANs are typically used to reduce broadcast traffic and to increase security. A group of network users assigned to a VLAN form a broadcast domain that is separate from other VLANs configured on the EFM modem. Packets are forwarded only between ports that are designated for the same VLAN. Untagged VLANs can be used to manually isolate user groups or subnets.

PVID - VLAN ID assigned to untagged frames received on the interface. (Default: 1)
If an interface is not a member of VLAN 1 and you assign its PVID to this VLAN, the interface will automatically be added to VLAN 1 as an untagged member. For all other VLANs, an interface must first be configured as an untagged member before you can assign its PVID to that group.

Link Type - Sets the port to accept the frame types: “Access” means the port can only receive or send untagged frame types. “Trunk” means that the prot can only receive or send tagged frame types.

3.5.2.2 Port-Based VLAN

Click Port-Based VLAN to configure the EFM modem.

Port-Based VLANs are VLANs where the packet forwarding decision is based on the destination MAC address and its associated port.

When using the port-based VLAN, the port is assigned to a specific VLAN independent of the user or system attached to the port. This means all users attached to the port should be members in the same VLAN. The network administrator typically performs the VLAN assignment. The port configuration is static and cannot be automatically changed to another VLAN without manual reconfiguration.

As with other VLAN approaches, the packets forwarded using this method do not leak into other VLAN domains on the network. After a port has been assigned to a VLAN, the port cannot send to or receive from devices in another VLAN.

For example,



The default setting is all ports connected which means all ports can communicate with each other. That is, there are no virtual LANs. The option is the most flexible but the least secure.



If you click the LAN1 to LAN4 only with DSL and Sniffing, there are port isolation means that each LANs port can only communicate with management port and cannot communicate with each other. This option is the most limiting but also the most secure.

3.5.2.3 Port-based QinQ

Click Port-Based QinQ to configure the EFM modem.

PVID (Port VID): It is an untagged member from 1 to 4094 of default VLAN.

TPID (Tag protocol identifier): 33024 for IEEE802.1Q

Link Type: Access means the port can receive or send untagged packets.
Trunk means that the prot can receive or send tagged packets.

A VLAN tag uses the tag protocol identifier (TPID) field to identify the protocol type of the tag. The value of this field, as defined in IEEE 802.1Q, is 0x8100 (33024).

VLAN Tag structure of an Ethernet frame



On devices of different vendors, the TPID of the outer VLAN tag of QinQ frames may have different default values. You can set or modify this TPID value, so that the QinQ frames, when arriving at the public network, carries the TPID value of a specific vendor to allow interoperation with devices of that vendor.

The TPID in an Ethernet frame has the same position with the protocol type field in a frame without a VLAN tag. To avoid chaotic packet forwarding and receiving, you cannot set the TPID value to any of the values in the table below.

Reserved protocol type values:

Protocol type	Value
ARP	0x0806
PUP	0x0200
RARP	0x8035
IP	0x0800
IPv6	0x86DD
PPPoE	0x8863/0x8864
MPLS	0x8847/0x8848
IPX/SPX	0x8137
IS-IS	0x8000
LACP	0x8809
802.1x	0x888E
Cluster	0x88A7
Reserved	0xFFFD/0xFFFE/0xFFFF

3.5.3 QoS

QoS(Quality of Service) refers to both a network's ability to deliver data with minimum delay, and the networking methods used to control the use of bandwidth. Without QoS, all traffic date is equally likely to be dropped when the network is congested. This can cause a reduction in network performance and mark the network inadequate for time-critical application such as video-on-demand.

Click QoS to configure QoS

QoS (Quality of Service) is to decide which PCs can get the priorities to pass though EFM modem once if the bandwidth is exhausted or fully saturated.
The priority modes have three types: Port Based Priority, VLAN Tag Priority and IP DSCP Priority. You can also set Disable the QoS function.

3.5.3.1 Port Based Priority

When you click Port Based Priority, it will show the following:

Select the ports to which the rule should be applied.
There six ports can applied: LAN1, LAN2, LAN3, LAN4, DSL and Sniffing
Scheduling Configuration item can setup the queue type from type 0 to type 3. Each queue type can setup the queue weight form 1 to 15.

The Queuing method is to configure queuing algorithms for outgoing traffic. Queuing algorithms allow EFM modem to maintain separate queues for packets from each individual source or flow and prevent a source from monopolizing the bandwidth.

The queuing algorithms:

WRR	**Weight Round Robin**
BE	**Best Effort**
SP	**Strictly Priority**

SP(Strictly Priority) services queues based on priority only. As traffic comes into the EFM modem, traffic on the highest priority queue, Q3 is transmitted first. When that queue empties, traffic on the next highest-priority queue, Q2 transmitted until Q2 empties, and then traffic is transmitted on Q1 and so on. If higher priority queues never empty, then traffic on lower priority never gets sent. The SP class is typically for video applications that require a fixed amount of bandwidth to be considered good quality.

BE(Best Effort) is used for data applications or any non-classified traffic. This would include e-mail, Internet browsing, data back-up etc. The BE class is for traffic that can afford to wait and not affect the overall outcome of the data application.

WRR(Weight Round Robin) services on a rotating basis and is activated only when a port has more traffic than it can handle. A queue is a given an amount of bandwidth irrespective of the incoming traffic on that port. The queue then moves to the back of the list. The next queue is given an equal amount of bandwidth, and then moves to the end of the list, and so on, depending on the number of queues being used, This works in a looping fashion until a queue is empty.

3.5.3.2 VLAN Tag Priority

When you click VLAN Tag Priority, it will show the following:

VLAN Tag Priority uses the tag field information which has been inserted into an Ethernet frame. If a port has an 802.1Q-compliant device attached (such as this modem), these tagged frames can carry VLAN membership information.

IEEE 802.1Q Tagged Frame for Ethernet:



User priority is giving eight ($2^3 = 8$) priority levels. The default value is 0, indicating normal treatment.

Priority Level	Traffic Type
0 (default)	Best Effort
1	Background
2	Spare
3	Excellent Effort
4	Controlled Load
5	Video, less than 100 milliseconds latency and jitter
6	Voice, less than 10 milliseconds latency and jitter
7	Network Control

Each Priority level can be set queue from 0 to 3.

Scheduling Configuration item can setup the type is from 1 to 3. Queue from 0 to 3 can set up their Queue Weight form 1 to 15.

[Example on using type1 (WRR) Scheduling Configuration]

For example, you can set the EFM modem use Weighted Round-Robin (WRR) queuing that specifies a relative weight of each queue. WRR uses a predefined relative weight for each queue that determines the percentage of service time to services each queue before moving on to the next queue. This prevents the head-of-line blocking that can occur with strict priority queuing.



On the table of scheduling Configuration:

Queue	0	1	2	3
Type 1	WRR	WRR	WRR	WRR
Weight	1	2	4	8

Set up the Weighted Round-Robin (Type 1) shares bandwidth by using scheduling weights 1, 2, 4 and 8 for queues 0 through 3 respectively.

VLAN Tag Priority:

Priority	0	1	2	3	4	5	6	7
Queue	1	0	0	1	2	2	3	3

According to above two tables, we can get the mapping QoS values to Egress Queues as the following:

Queue	0	1	2	3
Priority	1,2	0,3	4,5	6,7



Serviced by weighted round robin (WRR)

3.5.3.3 IP DSCP Priority

Differentiated Services (DiffServ) is a class of service(CoS) model that enhances best-effort Internet services by differentiating traffic by users, service requirements and other criteria. Packet are specifically marked, allowing network nodes to provide different levels of service, as appropriate for video playback, voice calls or other delay-sensitive applications, via priority queuing or bandwidth allocation.

DiffServ defines a new DS(Differentiated Services) field to replace the Type of Service(ToS) field in the IP header. The DS field contains a 2-bits unused field and 6-bits DSCP field which can define up to 64 service levels.

The following figure illustrates the DS field:



The DSCP value used to identify 64 levels (2^6=64) of service determines the forwarding behavior that each packet gets across the DiffServ network. Based on the marking rule different kinds of traffic can be marked for different priorities of forwarding. Resources can then be allocated according to the DSCP values and the configured policies.

The following is an illustration about how the bits are used in DSCP field.

Bit 0	Bit 1	Bit 2	Precedence	Usage
1	1	1	7	Stays the same(link layer and routing protocol keep alive)
1	1	0	6	Stays the same(used for IP routing Protocols)
1	0	1	5	Express Forwarding (EF)
1	0	0	4	Class 4
0	1	1	3	Class 3
0	1	0	2	Class 2
0	0	1	1	Class 1
0	0	0	0	Best effort

Bit 3	Bit 4	Bit 5	Usage	Meaning
0	--	--	Delay	Normal
1	--	--	Delay	Low
--	0	--	Throughput	Normal
--	1	--	Throughput	High
--	--	0	Reliability	Normal
--	--	1	Reliability	High

The standardized DiffServ field of the packet is marked with a value so that the packet receives a particular forwarding treatment at each network node.

RFC 2597 defines the assured forwarding (AF) classes. There are four AF classes, AF1x through AF4x. Within each class, there are three drop probabilities. Depending on a given network's policy, packets can be selected for a PHB based on required throughput, delay, jitter, loss, or according to priority of access to network services.

Classes 1 through 4 are referred to as AF classes.

The following table illustrates the DSCP coding for specifying the AF class with the probability. Bits 0, 1, and 2 define the class; bits 3 and 4 specify the drop probability; bit 5 is always 0.

	Class 1	Class 2	Class 3	Class 4
Low Drop	001010 AF11 DSCP 10	010010 AF21 DSCP 18	011010 AF31 DSCP 26	100010 AF41 DSCP 34
Medium Drop	001100 AF12 DSCP 12	010100 AF22 DSCP 20	011100 AF32 DSCP 28	100100 AF42 DSCP 36
High Drop	001110 AF13 DSCP 14	010110 AF23 DSCP 22	011110 AF33 DSCP 30	100110 AF43 DSCP 38

When you click IP DSCP(Differentiated Services Code Point) Priority, it will show the following:


SHDSL.bis EFM
Home
Basic
Advanced
Status
Admin
Utility
ADVANCED - QoS
Quality of Service Parameters:
Priority Mode:
Mode: Disable Port Based Priority VLAN Tag Priority IP DSCP Priority
Scheduling Configuration:
Operation
Queue
0 1 2 3
Type 1 WRR WRR WRR WRR
Type 2 BE BE BE SP
Weight 1 2 4 8
BASIC
ADVANCED
SHDSL.bis EFM
VLAN
QoS
Rate Control
STATUS
ADMIN
UTILITY
IP DSCP Priority:
DSCP Queue DSCP Queue DSCP Queue DSCP Queue
0 0 16 1 32 2 48 2
1 0 17 1 33 2 49 2
2 0 18 1 34 2 50 2
3 0 19 1 35 2 51 2
4 0 20 1 36 2 52 2
5 0 21 1 37 2 53 2
6 0 22 1 38 2 54 2
7 0 23 1 39 2 55 2
8 0 24 2 40 3 56 2
9 0 25 2 41 3 57 2
10 0 26 2 42 3 58 2
11 0 27 2 43 3 59 2
12 0 28 2 44 3 60 2
13 0 29 2 45 3 61 2
14 0 30 2 46 3 62 2
15 0 31 2 47 3 63 2
Cancel
Reset
Finish

Each DSCP value (from 0 to 63) is mapped to a Queue value (from 0 to 3) from the drop-down list box. The number 0 represents the lowest priority and number 3 represents the highest priority and according various queuing strategies to tailor performance to requirements. You are easy to change the table setting. If you want to save the changes, click Finish.

When click finish, there will have a QoS parameters review page for your confirm.

To let the configuration that you have changed take effect, click Restart to reboot system.
If you want to continue the setup procedure, click Continue is O.K.

3.5.4 Rate Control

Click Rate Control to configure the EFM modem.



Limiting bandwidth to specific users and ports helps control network congestion, ensure high performance, create efficient networks, and prevent a small number of users from monopolizing network bandwidth.

Rate control can be used to intelligently manage bandwidth allocation in the networking. It can prevent one user or device from dominating the available network bandwidth, and it allows IT managers to allocate greater bandwidth to the departments and applications that need it.



You can setup the date rates limit on each port. The date rates are: No limit, 128K, 256K, 512K, 1M and 2M. The default setting is No limit on each ports.

3.6 Status

When you click STATUS You can monitor the following : SHDSL.bis EFM, MGMT, LAN and INTERFACE

3.6.1 SHDSL .Bis EFM

SHDSL.bis status including run-time device status : mode and Bitrate and Performance information: SNR margin, atteunation and CRC error count.

4-pairs model (8 wire model)will showed as following, you can know about their four channel run-time status(from channel A to D).

Below display screen is come from four pair model(8 wire model):


SHDSL.bis EFM
Home
Basic
Advanced
Status
Admin
Utility
STATUS - SHDSL.bis
Status Information:
Run-Time Device Status:
SHDSL.bis Status | Channel A | Channel B | Channel C | Channel D
SHDSL bis Mode | CPE Side | CPE Side | CPE Side | CPE Side
Line Rate(n*64) | 0 Kbps | 0 Kbps | 0 Kbps | 0 Kbps
Performance Information:
Item | Local Side | Remote Side
Channel A | Channel B | Channel C | Channel D | Channel A | Channel B | Channel C | Channel D
SNR Margin | 0 dB | 0 dB | 0 dB | 0 dB | 0 dB | 0 dB | 0 dB | 0 dB
Attenuation | 0 dB | 0 dB | 0 dB | 0 dB | 0 dB | 0 dB | 0 dB | 0 dB
CRC Error Count | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0
Clear CRC Error
BASIC
ADVANCED
SHDSL.bis EFM
VLAN
QoS
STATUS
SHDSL.bis EFM
MGMT
LAN
INTERFACE
ADMIN
UTILITY

Below display screen is come from one pair model(2 wire model):

If two EFM modem have been linking togetor, you can know about their run-time line rate status and performance information from this screen.

Note: CPE side's line rate according to the setting of CO side.

If you want to clear the performance data on ERC Error Count, click Clear CRC Error is O.K.

3.6.2 MGMT

MGMT status will display the MGMT interface information.



You can view the general status of MGMT interface and DHCP client table.

3.6.3 LAN

LAN status will prompt the setting on IP type, IP address and Subnet mask.



For example,It shows the IP type of LAN interface is Fixed:



3.6.4 Interface

INTERFACE status inculdes MGMT and LAN statistics information.



Octet is a group of 8 bits, often referred to as a byte.

Packet is a formatted block of data carried by a packet mode computer networks, often referred to the IP packet.

InOctets	**The field shows the number of received bytes on this port**
InPactets	**The field shows the number of received packets on this port**
OutOctets	**The field shows the number of transmitted bytes on this port**
OutPactets	**The field shows the number of transmitted packets on this port**
InDiscards	**The field shows the discarded number of received packets on this port**
OutDiscards	**The field shows the discarded number of transmitted packets on this port**

3.7 Administration

This session introduces Administration including SECURITY and SNMP (simple network management protocol).

3.7.1 Security

For system secutiry, suggest to change the default user name and password in the first setup otherwise unauthorized persons can access the EFM modem and change the parameters.

Press Security to setup the parameters.

For better security, change the Supervisor ID and Supervisor password for the EFM modem. If

you don't set them, all users can be able to access the EFM modem using the default Supervisor ID and Supervisor Password is *"root"*.

You can authorize five legal users to access the EFM modem via telnet or console only. There are two UI modes, menu driven mode and command mode to configure the EFM modem.
The default user name on and Password are *"admin"*.
There are two UI modes, menu and command mode for telnet or console mode to setup the EFM modem. The menu is meaning menu driven interface mode and Command is meaning line command mode. We will not discuss command mode in this manual.

Telnet Console mode:



Web Brower mode:



There have a Telnet Port number setting. The default value is 23.



Legal address pool will setup the legal IP addresses from which authorized person can configure the EFM modem. This is the more secure function for network administrator to setup the legal address of configuration.

Configured 0.0.0.0 will allow all hosts on Internet or LAN to access the EFM modem.
Leaving blank of trust host list will cause blocking all PC from WAN to access the EFM modem.
On the other hand, only PC in LAN can access the EFM modem.
If you type the exact IP address in the filed, only the host can access the EFM modem.

Click Finish to finish the setting.
The browser will prompt the configured parameters and check it before writing into NVRAM.
Press Restart to restart the EFM modem working with the new parameters and press Continue to setup other parameters.

3.7.2 SNMP

Simple Network Management Protocol (SNMP) provides for the exchange of messages between a network management client and a network management agent for remote management of network nodes. These messages contain requests to get and set variables that exist in network nodes in order to obtain statistics, set configuration parameters, and monitor network events. SNMP communications can occur over the LAN or WAN connection.

The EFM modem can generate SNMP traps to indicate alarm conditions, and it relies on SNMP community strings to implement SNMP security.

This EFM modem support both MIB I and MIB II.

Click SNMP to configure the parameters.

3.7.2.1 Community Pool

An SNMP community is the group that devices and management stations runing SNMP belong to. It helps define where information is sent. The community name is used to identify the group. A SNMP device or agent may belog to more than one community. It will not requests from management stations that do not belong to one of its communities.

SNMP default communities are:

Access Right	Community
Read	public
Write	private

Press Modify to set up community pool.



In the table of current community pool, you can setup the access authority.

Status: Enable for turn on the SNMP function

Disable for turn off the SNMP function

Access Right: Deny for deny all access

Read for access read only

Write for access read and write.

Community: It serves as password for access right.

After configuring the community pool, press Finish.

The browser will prompt the configured parameters and check it before writing into NVRAM. Press Restart to restart the EFM modem working with the new parameters and press Continue to setup other parameters.

3.7.2.2 Trap Host Pool

In the table of current trap host pool, you can setup the trap host.

SNMP trap is an informational message sent from an SNMP agent to a manager. It is a management station (SNMP application) that receives traps.

If no trap host pool is defined, no traps are issued.

Press Modify to set up trap host pool.



Version: select version for trap host. (Version 1 is for SNMPv1; Version 2 for SNMPv2).

Disable for turn off

IP Address: type the trap host IP address

Community: type the community password.

Press OK to finish the setup.

The browser will prompt the configured parameters and check it before writing into NVRAM. Press Restart to restart the EFM modem working with the new parameters and press Continue to setup other parameters.

3.8 Utility

This section will describe the UTILITY of the EFM modem.

The UTILITY menu including:

SYSTEM INFO: system information,

CONFIG TOOL: load the factory default configuration,

UPGRADE: upgrade the firmware

LOGOUT: logout the system

RESTART: restart the EFM modem.

3.8.1 System Info

For review the information, click SYSTEM INFO to display the screen as shown below.

You can check the MCSV, Software Version, Chipset, Firmware Version, Host Name and System Up Time.

The System Up Time item let you know the EFM modem how long time after power on.

3.8.2 Config Tool

This configuration tool has three functions: load Factory Default, Restore Configuration, and Backup Configuration.

Press CONFIG TOOL, you can view the following:



Choose the function and then press Finish.

Load Factory Default: It will load the factory default parameters to the EFM modem.

Note: This action will change all of the settings to factory default. On the other hand, you will lose all the existing configured parameters.

Restore Configuration:

In case of the configuration crushed occasionally, it will help you to recover the backup configuration easily.

Click Finish after selecting Restore Configuration.

Browse the route of backup file then press finish. The EFM modem will automatically restore the saved configuration.

Backup Configuration:

After configuration, suggest using the function to backup your EFM modem parameters in the PC. Select the Backup Configuration and then press Finish. Browse the place of backup file named backup. Press Finish. The EFM modem will automatically backup the configuration.

3.8.3 Upgrade

You can upgrade the firmware of EFM modem using the upgrade function.

Press Upgrade in UTILITY menu.

Type the path and file name of the firmware file you wish to upload to the EFM modem in text box or click Browse to locate it. Press OK button to upgrade. The system will reboot automatically after finishing. (Firmware upgrades are only applied after a reboot)

After the firmware upgrade process is complete, you can see the SYSTEM INFO screen to verify your current firmware version number.

3.8.4 Logout

To exit the web configurator, press LOGOUT. You have to log in with your password again after you log out. This is recommended after you finish a management session for security reasons.



3.8.5 Restart

For restarting the EFM modem, press Restart to reboot the EFM modem.

SHDSL.bis EFM
Home
Basic
Advanced
Status
Admin
Utility
UTILITY - RESTART
This page offers you the opportunity to restart your SOHO Router. When the restart button be clicked, the SOHO Router is restarting and your browser session will be disconnected. This may appear as if your browser session is hungup. After the server restarts, you may either press your browser's reload button, or close your browser and re-open it several minutes later.
!!
Cancel
Restart
BASIC
ADVANCED
STATUS
ADMIN
UTILITY
SYSTEM INFO
CONFIG TOOL
UPGRADE
LOGOUT
RESTART

When you press Restart, display screen is as following:

It show the configuration is success. When the system have rebooted later, you can re-open the browser.

4 Configuration use Serial Console and Telnet with Menu Driven Interface

4.1 Introduction

4.1.1 Login to the Console Interface

The console port is a RJ-48C connector that enables a connection to a PC for monitoring and configuring the EFM modem. Use the supplied serial cable with a female DB-9 connector to serial port of PC and RJ-48C module jack connector to EFM modem's console port. Start your terminal access program by terminal emulation program or Hyper Terminal and configure its communication parameters to match the following default characteristics of the console port:

Parameter	*Value*
Baud rate	**9600**
Data Bits	**8**
Parity Check	**None**
Stop Bits	**1**
Flow-control	**None**

After finished the parameter settings, press the SPACE key until the login screen appears. When you see the login screen, you can logon to this EFM Modem.
Note: Only SPACE key invoke the login prompt. Pressing other keys does not work.
The system asks for User and Password, please enter "admin" both for the factory default password. As show in the following:

User: admin
Password: *****

4.1.2 Telnet login

The EFM modem also supports telnet for remote management.
Make sure the correct Ethernet cable connected the MGMT port of EFM modem to your computer. The MGMT indicator on the front panel shall light if a correct cable is used. Starting your Telnet client with VT100 terminal emulation and connecting to the management IP of EFM modem, wait for the login prompt appears. Input User and Password after login screen pop up. The system asks for User and Password, please enter "admin" both for the factory default password. As show in the following:

User: admin

Password: *****

Note: The default IP address is 192.168.1.1. So that the line command is “telnet 192.168.1.1” on DOS mode.

4.1.3 Menu Driven Interface Commands

Before changing the configuration, familiarize yourself with the operations list in the following table. The operation list will be shown on the window.



Menu Driven Interface Commands:

Keystroke	Description
[UP] or I	**Move to above field in the same level menu.**
[DOWN] or K	**Move to below field in the same level menu.**
[LEFT] or J	**Move back to previous menu.**
[RIGHT] , L or [ENTER]	**Move forward to submenu.**
[HOME]or U	**Move to first field**
[END] or O	**Move to last field**
[TAB]	**To choose another parameters.**
Ctrl + C	**To quit the configuring item.**
Ctrl + Q	**For help**

For serial console and Telnet management, the EFM Modem implements the menu driven interface. It can show you all of available commands for you to select. You don’t need to remember the command syntax and save your time on typing the whole command line.

The following figure gives you an example of the menu driven interface. In the menu, you scroll up/down by pressing key I / K ; select one command by key L, and go back to a higher level of menu by key J ; you also can scroll to top/bottom by pressing Key U/O.

For example, to show the system information, just logon to the EFM Modem, move down the cursor by pressing key K twice and select "show" command by key L, you shall see a submenu and select "system" command in this submenu, then the system will show you the general information.

You can press the Enter key for select command same as key L.



4.1.4 Window structure

From top to bottom, the window is divided into four parts:

Product name: SHDSL.bis EFM Bridge

Menu field: Menu tree prompts on this field. Symbol ">>" indicates the cursor place.

Configuring field: You will configure the parameters in this field. < parameters > indicates the parameters you can choose and < more…> indicates that there have submenu in the title.

Operation command for help

4.2 Main Menu Tree

The main menu tree is as following figures. All of the configuration commands are placed in the subdirectories of Enable protected by supervisor password. Unauthorized user cannot change any configurations but can view the status and configuration of the EFM Modem and

use ping command to make sure the EFM modem is working.

4.2.1 Menu tree for authorized user

If you are the authorized user, the menu tree is the following:



If you are the authorized user, you can view the display screen as the following:

```
                          SHDSL.bis EFM Bridge
------------------------------------------------------------------------------
>> enable              Modify command privilege
   setup               Configure system
   status              Show running system status
   show                View system configuration
   write               Update flash configuration
   reboot              Reset and boot system
   ping                Packet internet groper command
   admin               Setup management features
   utility             TFTP upgrade utility
   exit                Quit system


------------------------------------------------------------------------------
Command: enable <CR>_
Message:




------------------------------------------------------------------------------
<I/K> Move up/down, <L/J> Select/Unselect, <U/O> Move top/bottom, <^Q> Help
```

4.2.2 Menu tree for unauthorized user

If you are the unauthorized user, the menu tree is the following:



If you are the unauthorized user, you can view the display screen as below. Only have view status, show system and ping function.

```
                          SHDSL.bis EFM Bridge
------------------------------------------------------------------------------
>> enable              Modify command privilege
   status              Show running system status
   show                View system configuration
   ping                Packet internet groper command
   exit                Quit system









------------------------------------------------------------------------------
Command: enable <CR>_
Message:




------------------------------------------------------------------------------
<I/K> Move up/down, <L/J> Select/Unselect, <U/O> Move top/bottom, <^Q> Help
```

4.3 Enable

To setup the EFM modem, move the cursor " >>" to enable and press enter key. While the screen appears, type the supervisor password. The default supervisor password is "*root*". The password will be prompted as " * " symbol for system security.

```
---------------------------------------------------------------------
Command: enable <CR>
Message: Please input the following information.

Supervisor password: ****
---------------------------------------------------------------------
```

In this sub menu, you can setup management features and upgrade software, backup the system configuration and restore the system configuration via utility tools.

For any changes of configuration, you have to write the new configuration to NVRAM and reboot the EFM modem to work with new setting.

The screen will prompt as follow.

```
---------------------------------------------------------------------------------
>> enable       Modify command privilege
   setup        Configure system
   status       Show running system status
   show         View system configuration
   write        Update flash configuration
   reboot       Reset and boot system
   ping         Packet internet groper command
   admin        Setup management features
   utility      TFTP upgrade utility
   exit         Quit system
---------------------------------------------------------------------------------
```

Command Description:

Command	Description
enable	Modify command privilege. When you login via serial console or Telnet, the EFM modem defaults to a program execution (read-only) privileges to you. To change the configuration and write changes to nonvolatile RAM (NVRAM), you must work in enable mode.
setup	To configure the product, you have to use the setup command.
status	View the status of product.
show	Show the system and configuration of product.
write	Update flash configuration. After you have completed all necessary setting, make sure to write the new configuration to NVRAM by “write” command and reboot the system, or all of your changes will not take effect.
reboot	Reset and boot system. After you have completed all necessary setting, make sure to write the new configuration to NVRAM and reboot the system by “reboot” command, or all of your changes will not take effect.
ping	Internet Ping command.
admin	You can setup management features in this command.
utility	Upgrade software and backup and restore configuration are working via “utility” command.
exit	Quit system

4.4 Setup

All of the setup parameters are located in the subdirectories of setup. Move the cursor " >>" to setup and press enter.

```
>> shdsl.bis        Configure SHDSL.bis parameters
   lan              Configure LAN interface profile
   vlan             Configure virtual LAN parameters
   qos              Configure Quality of Service parameters
   rate             Configure Rate Control parameters
   mgmt             Configure management interface profile
   dhcp             Configure DHCP parameters
   dns_proxy        Configure DNS proxy parameters
   hostname         Configure local host name
   default          Restore factory default setting
```

4.4.1 SHDSL.bis

You can setup the SHDSL.bis parameters by the command shdsl.bis. Move the cursor " >> " to shdsl.bis and press enter.

```
>> mode             Configure shdsl.bis mode
   link             Configure shdsl.bis link
   annex            Configure shdsl.bis annex type
   tcpam            Configure shdsl.bis TCPAM type
   maxMainRate      Configure shdsl.bis max main data rate
   snrMagrin        Configure Shdsl.bis SNR margin
   lineProbe        Configure shdsl.bis line probe
   clear            Clear current CRC error count
```

4.4.1.1 Mode

There are two types of SHDSL.bis mode, STU-C and STU-R. STU-C means the terminal of central office and STU-R customer premise equipment.

4.4.1.2 Link

Line type means how many wire you want to use on SHDSL.bis connection. Link type will be 2-wire, 4-wire or 8-wire mode according to the product type. 4-wire product can be worked under 2-wire mode. 8-wire product can be worked under 4-wire mode and 2-wire mode.

Link type / EFM modem	2-wire	4-wire	8-wire
2-wire model	●		
4-wire model	●	●	
8-wire model	●	●	●

4.4.1.3 Annex

There are two types of SHDSL .bis Annex type: Annex-AF, and Annex-BG.

4.4.1.4 TCPAM

There are two TCPAM modes for SHDSL .Bis: TCPAM-16 and TCPAM-32. You also can select Auto mode.

4.4.1.5 Maximum main rate

You can setup the SHDSL.bis main rate is in the multiple of 64kbps , 128kpbs or 256 kpbs, according using which model.

Main Rate (Unit: kbps)

SHDSL.bis EFM Modem	multiple	Annex AF/BG	
		TCPAM-16	TCPAM-32
		N=3~60	N=12~89
2-wire model	64	192 ~ 3840	768 ~ 5696
4-wire model	128	384 ~ 7680	1536 ~ 11392
8-wire model	256	768 ~ 15360	3072 ~ 22784

4.4.1.6 SNR Margin

Generally, you aren't necessary to change SNR margin, which range is from -10 to 21. SNR margin is an index of line connection. You can see the actual SNR margin in STATUS SHDSL.bis. The larger is SNR margin; the better is line connection quality. If you set SNR margin in the field as 5, the SHDSL.bis connection will drop and reconnect when the SNR margin is lower than 5. On the other hand, the device will reduce the line rate and reconnect for better line connection.

4.4.1.7 Line Probe

For adaptive mode, you can setup the Line Probe is Enable. The EFM modem will adapt the data rate according to the line status. Otherwise, setup to Disbale.

4.4.1.8 Clear

The Clear command can clear CRC error count.

SHDSL.bis:

Mode	**□STU-C □STU-R**
Link Type	**□2-wire □4-wire □8-wire**
Annex Type	**□AF □BG**
TCPAM	**□Auto □TCPAM-16 □TCPAM-32**
Max Main Rate	**(3~89)**
SNR Margin	**(-10~21)**
Line Probe	**□Disable □Enable**

4.4.2 LAN

You can setup the LAN parameters by the command lan. Move the cursor " >> " to lan and press enter.

```
--------------------------------------------------------------------------------
 Command: setup lan <1~1>
 Message: Please input the following information.

 Interface number <1~1>: 1

--------------------------------------------------------------------------------
```

The default interface number is 1.

LAN interface parameters can be configured Link type, LAN IP address and subnet mask.

Select link_type item:

```
--------------------------------------------------------------------------------
>> link_type          Configure Link type
   address            LAN   address and subnet mask
--------------------------------------------------------------------------------
```

```
--------------------------------------------------------------------------------
Command: setup lan 1 link_type <Disable|Dynamic|Static>
 Message: Please input the following information.

 Link type (TAB Select) <Disable>:
--------------------------------------------------------------------------------
```

You can select the lan 1 link type is Disable, Dynamic or Static.

Select address item:

```
--------------------------------------------------------------------------------
   link_type          Configure Link type
>> address            LAN   address and subnet mask
--------------------------------------------------------------------------------
```

```
--------------------------------------------------------------------------------
 Command: setup lan 1 address <ip> <netmask>
 Message: Please input the following information.

 IP address (ENTER for default) <192.168.2.1>:
 Subnet mask (ENTER for default) <255.255.255.0>:

--------------------------------------------------------------------------------
```

You can configure LAN IP address, subnet mask. The default value is 192.168.2.1 and 255.255.255.0

LAN:

Link Type	**□Disable □Dynamic □Static**
IP Address	
Subnet mask	

4.4.3 VLAN

Virtual LAN (VLAN) is defined as a group of devices on one or more LANs that are configured so that they can communicate as if they were attached to the same wire, when in fact they are located on a number of different LAN segments. Because VLAN is based on logical instead of physical connections, it is extremely flexible.

You can setup the Virtual LAN (VLAN) parameters in VLAN command. The EFM modem support the implementation of VLAN-to-PVC only for bridge mode operation, i.e., the VLAN spreads over both the CO and CPE sides, where there is no layer 3 routing involved. The unit supports up to 8 active VLANs with shared VLAN learning (SVL) bridge out of 4096 possible VLANs specified in IEEE 802.1Q.

Move the cursor " >> " to vlan and press enter.

```
>> mode          Trigger virtual LAN function
   modify        Modify virtual LAN table
   pvid          Modify port default VID
   link_mode     Modify port link type
   list          Show VLAN configuration
```

To active the VLAN function, move the cursor " >> " to mode and press enter. The products support two types of VLAN, 802.1Q and Port-Based.

The 802.1Q defines the operation of VLAN bridges that permit the definition, operation, and administration of VLAN topologies within a bridged LAN infrastructure.

Port-Based VLANs are VLANs where the packet forwarding decision is based on the destination MAC address and its associated port.

4.4.3.1 Mode

User can choose two types of VLAN: 802.1Q Tag-Based VLAN or Port Based VLAN. When you don't use VLAN, set to Disable.

```
---------------------------------------------------------------------------
 Command: setup vlan mode <Disable|8021Q|Port>
 Message: Please input the following information.

 Trigger VLAN function (TAB Select) <Disable>:
---------------------------------------------------------------------------
```

VLAN Mode:

VLAN Mode	▫Disable ▫802.1Q Tag VLAN ▫Port Based VLAN

4.4.3.2 802.11Q VLAN

To modify the VLAN rule, move the cursor to modify and press enter.

```
--------------------------------------------------------------------------------
  Command: setup vlan modify <1~8> <0~4094> <string>
  Message: Please input the following information.

  VLAN table entry index <1~8>: 1
  VID value (ENTER for default) <1>: 10
  VLAN port membership (ENTER for default) <111111>:
--------------------------------------------------------------------------------
```

The VLAN Port membership represents with string 1 or 0.

VLAN port membership is a 6-digit binary number in which bit 0 to bits 5 represents LAN1 to LAN4, DSL and Sniffing ports respectively.

For example: [setup vlan modify 1 10 111111] means use index as 1 , VID = 10 and all six ports are as same membership (VLAN ID=10).

Use PVID command to change the member port to untagged members:

```
--------------------------------------------------------------------------------
  Command: setup vlan pvid <1~6> <1~4094>
  Message: Please input the following information.

  Port index <1~6>:
VID value (ENTER for default) <1>:
--------------------------------------------------------------------------------
```

PVID (Port VID) : It is an untagged member from 1 to 4094 of default VLAN.

For example:

[set vlan pvid 1 100]

[set vlan pvid 2 100]

[set vlan pvid 3 100]

[set vlan pvid 4 100]

[set vlan pvid 5 100]

[set vlan pvid 6 100]

Those means all untagged on all ports are as same membership (VLAN ID=100)

To modify the link type of the port, move the cursor to link_mode and press enter. There are two types of link: access and trunk. Trunk link will send the tagged packet form the port and Access link will send un-tagged packet form the port. The port index 1 to 4 represents LANs ports, index 5 represents DSL and index 6 represents Sniffing respectively.

```
--------------------------------------------------------------------------------
  Command: setup vlan link_mode <1~6> <Access|Trunk>
  Message: Please input the following information.

  Port index <1~6>: 1
  Port link type (TAB Select) <Access>:
--------------------------------------------------------------------------------
```

Access	**The port can receive or send untagged packets**
Trunk	**The port can receive or send tagged packets**

802.11Q VLAN:

		1	2	3	4	5	6
No.	**VID**	**LAN1**	**LAN2**	**LAN3**	**LAN4**	**DSL**	**Sniffing**
1							
2							
3							
4							
5							
6							
7							
8							
PVID							
Link Type		☐Access ☐Trunk	☐Access ☐Trunk	☐Access ☐Trunk	☐Access ☐Trunk	☐Access ☐Trunk	☐Access ☐Trunk

4.4.3.3 Port Based VLAN

With port-based VLAN, the port is assigned to a specific VLAN independent of the user or system attached to the port. This means all users attached to the port should be members in the same VLAN. The port based setting performs the VLAN assignment. The port configuration is static and cannot be automatically changed to another VLAN without manual reconfiguration.

For Port Based VLAN, user must set up the table using 802.11Q methods. But don't care the value of VID , PVID or link type.

Port Based VLAN:

No.	LAN1	LAN2	LAN3	LAN4	DSL	Sniffing
1						
2						
3						
4						
5						
6						
7						
8						

Use List command can show the setup table for you check:

```
-------------------------------------------------------------------------------
Virtual LAN Parameter
  VLAN Mode                          : Port-Based VLAN

Virtual LAN Table
  No LAN1 LAN2 LAN3 LAN4   DSL Sniffing
  --   ----  ----  ----  ----  ---- --------
   1    1     1     1     1     1     1
   2    -     -     -     -     -     -
   3    -     -     -     -     -     -
   4    -     -     -     -     -     -
   5    -     -     -     -     -     -
   6    -     -     -     -     -     -
   7    -     -     -     -     -     -
   8    -     -     -     -     -     -

  -------------------------------------------------------------------------------
```

4.4.4 QoS

QoS(Quality of Service) is to decide which PCs can get the priorities to pass though EFM modem once if the bandwidth is exhausted or fully saturated.

Move the cursor " >> " to qos and press enter.

```
>> mode          Trigger Quality of Service function
   qweight       Modify queue weight
   qSchdl        Modify queue schedule type
   portPri       Modify port priority
   vlanTagPri    Modify VLAN TAG priority
   ipDscpPri     Modify IP DSCP priority
   list          Show QoS configuration
```

4.4.4.1 Mode

User can choose three types of QoS: Port Based, VLAN Tag, IP DSCP. When you don't use QoS, set to Disable.

```
Command: setup qos mode <Disable|PortBased|VlanTag|IpDscp>
Message: Please input the following information.

Trigger qoS function (TAB Select) <Disable>:
```

QoS Mode:

QoS Mode	▫Disable ▫Port Based ▫VLAN Tag ▫IP DSCP

4.4.4.2 Queue weight

This setting can set weight value on each queue.

```
Command: setup qos qweight <0~3> <1~15>
Message: Please input the following information.

Queue index <0~3>: 0
Weight value (ENTER for default) <1>: 1
```

For example, the default values are as following

[setup qos qweight 0 1]

[setup qos qweight 1 2]

[setup qos qweight 2 4]

[setup qos qweight 3 8]

Queue Weight:

Queue Index	0	1	2	3
Weight Value				

4.4.4.3 Queue schedule

There are two type queue schedule: Type 1 and type 2 for your selection.
The schedule types according to following table:

	Queue 0	Queue 1	Queue 2	Queue 3
Type 1	WRR	WRR	WRR	WRR
Type 2	BE	BE	BE	SP

```
--------------------------------------------------------------------------------
Command: setup qos qSchdl <Type1|Type2|>
Message: Please input the following information.

Operation type (TAB Select) <Type1>: Type1

--------------------------------------------------------------------------------
```

The queuing algorithms:

WRR	Weight Round Robin
BE	Best Effort
SP	Strictly Priority

SP(Strictly Priority) services queues based on priority only. As traffic comes into the EFM modem, traffic on the highest priority queue, Q3 is transmitted first. When that queue empties, traffic on the next highest-priority queue, Q2 transmitted until Q2 empties, and then traffic is transmitted on Q1 and so on. If higher priority queues never empty, then traffic on lower priority never gets sent. The SP class is typically for video applications that require a fixed amount of bandwidth to be considered good quality.

BE(Best Effort) is used for data applications or any non-classified traffic. This would include e-mail, Internet browsing, data back-up etc. The BE class is for traffic that can afford to wait and not affect the overall outcome of the data application.

WRR(Weight Round Robin) services on a rotating basis and is activated only when a port has more traffic than it can handle. A queue is a given an amount of bandwidth irrespective of the incoming traffic on that port. The queue then moves to the back of the list. The next queue is given an equal amount of bandwidth, and then moves to the end of the list, and so on, depending on the number of queues being used, This works in a looping fashion until a queue is empty.

Queue Schedule:

Queue Schedule	□Type 1 □Type 2

4.4.4.4 Port Based Priority QoS

Command: setup qos portPri <1~6> <0~3>
Message: Please input the following information.

Port index <1~6>: 1
Queue index (ENTER for default) <3>: 3

Set up queue value (0, 1, 2 or 3) on each ports.

Port Based Priority QoS:

Port	1(LAN1)	2(LAN2)	3(LAN3)	4(LAN4)	5(DSL)	6(Sniffing)
Queue Index						

4.4.4.5 VLAN Tag Priority QoS

```
--------------------------------------------------------------------------
Command: setup qos vlanTagPri <0~7> <0~3>
Message: Please input the following information.

VLAN TAG index <0~7>: 0
Queue index (ENTER for default) <1>: 1

--------------------------------------------------------------------------
```

Set up queue index(0, 1, 2 or 3) on each Priority of VLAN Tag.

VLAN Tag Priority uses the tag field information which has been inserted into an Ethernet frame. If a port has an 802.1Q-compliant device attached (such as this modem), these tagged frames can carry VLAN membership information.

User priority is giving eight priority levels. The default value is 0, indicating normal treatment.

Priority Level	Traffic Type
0 (default)	Best Effort
1	Background
2	Spare
3	Excellent Effort
4	Controlled Load
5	Video, less than 100 milliseconds latency and jitter
6	Voice, less than 10 milliseconds latency and jitter
7	Network Control

Each Priority level can be set queue index from 0 to 3.

For example, you can set the EFM modem use Weighted Round-Robin (WRR) queuing (Type 1) that specifies a relative weight of each queue. WRR uses a predefined relative weight for each queue that determines the percentage of service time to services each queue before moving on to the next queue.

VLAN Tag Priority QoS:

VLAN Tag Index	0	1	2	3	4	5	6	7
Queue Index								

4.4.4.6 IP DSCP Priority Qos

Differentiated Services (DiffServ) is a class of service(CoS) model that enhances best-effort Internet services by differentiating traffic by users, service requirements and other criteria. Packet are specifically marked, allowing network nodes to provide different levels of service, as appropriate for video playback, voice calls or other delay-sensitive applications, via priority queuing or bandwidth allocation.

The DSCP value used to identify 64 levels of service determines the forwarding behavior that each packet gets across the DiffServ network. Based on the marking rule different kinds of traffic can be marked for different priorities of forwarding. Resources can then be allocated according to the DSCP values and the configured policies.

Set up queue index (0, 1, 2 or 3) on each DSCP:

Command: setup qos ipDscpPri <0~63> <0~3>
Message: Please input the following information.

IP DSCP index <0~63>: 0
Queue index (ENTER for default) <0>:

IP DSCP QoS:

DSCP	Queue Index	DSCP	Queue Index	DSCP	Queue Index	DSCP	Queue Index
0		16		32		48	
1		17		33		49	
2		18		34		50	
3		19		35		51	
4		20		36		52	
5		21		37		53	
6		22		38		54	
7		23		39		55	
8		24		40		56	
9		25		41		57	
10		26		42		58	
11		27		43		59	
12		28		44		60	
13		29		45		61	
14		30		46		62	
15		31		47		63	

4.4.4.7 List

This command can show the setup table for you check.

4.4.5 RATE

Move the cursor " >> " to Rate and press enter.

```
---------------------------------------------------------------------------
 >> port                  Modify port rate
    list                  Show Rate Control configuration

---------------------------------------------------------------------------
```

Select which port you want to modify and then set up the data rate.

```
---------------------------------------------------------------------------
 Command: setup rate port <1~6> <no_limit|128K|256K|512K|1M|2M>
 Message: Please input the following information.

 Port index <1~6>: 1
 rate (TAB Select) <no_limit>:

 ---------------------------------------------------------------------------
```

Setup data rate per port:

Port 1	LAN1	□No limit	□128K	□256K	□512K	□1M	□2M
Port 2	LAN2	□No limit	□128K	□256K	□512K	□1M	□2M
Port 3	LAN3	□No limit	□128K	□256K	□512K	□1M	□2M
Port 4	LAN4	□No limit	□128K	□256K	□512K	□1M	□2M
Port 5	DSL	□No limit	□128K	□256K	□512K	□1M	□2M
Port 6	Sniffing	□No limit	□128K	□256K	□512K	□1M	□2M

4.4.6 MGMT

Move the cursor " >> " to mgmt and press enter.

MGMT interface parameters can be configured MGMT IP address and subnet mask.

```
---------------------------------------------------------------------
Command: setup mgmt <1~1> <more...>
 Message: Please input the following information.

 Interface number <1~1>:

---------------------------------------------------------------------
```

The EFM modem only has one MGMT interface can use, so that use the default interface number is 1. The default IP address and subnet mask are 196.168.1.1 and 255.255.255.0 .

```
>> address              MGMT IP address and subnet mask
```

```
---------------------------------------------------------------------
Command: setup mgmt 1 address <ip> <netmask>
 Message: Please input the following information.
```

IP address (ENTER for default) <192.168.1.1>:
Subnet mask (ENTER for default) <255.255.255.0>:

MGMT interface:

IP Address	
Subnet Mask	

4.4.7 DHCP

Dynamic Host Configuration Protocol (DHCP) is a communication protocol that lets network administrators to manage centrally and automate the assignment of Internet Protocol (IP) addresses in an organization's network. Using the Internet Protocol, each machine that can connect to the Internet needs an unique IP address. When an organization sets up its computer users with connection to the Internet, an IP address must be assigned to each machine.
Without DHCP, the IP address must be entered manually at each computer. If computers move to another location in another part of the network, a new IP address must be entered. DHCP lets a network administrator to supervise and distribute IP addresses from a central point and automatically sends a new IP address when a computer is plugged into a different place in the network.

4.4.7.1 DHCP Server

Dynamic Host Configuration Protocol (DHCP) is a communication protocol that lets network administrators to manage centrally and automate the assignment of Internet Protocol (IP) addresses in an organization's network. Using the Internet Protocol, each machine that can connect to the Internet needs a unique IP address. When an organization sets up its computer users with a connection to the Internet, an IP address must be assigned to each machine.

Without DHCP, the IP address must be entered manually at each computer. If computers move to another location in another part of the network, a new IP address must be entered. DHCP lets a network administrator to supervise and distribute IP addresses from a central point and automatically sends a new IP address when a computer is plugged into a different place in the network.

To configure DHCP server, move the cursor to dhcp and press enter.

```
>> generic          DHCP server generic parameters
   fixed            DHCP server fixed host IP list
```

```
    list                Show DHCP configuration
```

The generic DHCP parameters can be configured via generic command.

```
>> active              Trigger DHCP server function
   gateway             Default gateway for DHCP client
   netmask             Subnet mask for DHCP client
   ip_range            Dynamic assigned IP address range
   lease_time          Configure max lease time
   name_server1        Domain name server1
   name_server2        Domain name server2
   name_server3        Domain name server3
```

Command	Description
Active	Trigger DHCP server function
Gateway	Configure default gateway for DHCP client
Net mask	Configure subnet mask for DHCP client
IP range	Configure dynamic assigned IP address range.
Lease time	Set up dynamic IP maximum lease time
Name server 1	Set up the IP address of name server #1
Name server 2	Set up the IP address of name server #2
Name server 3	Set up the IP address of name server #3

DHCP Server:

DHCP Server	▫Disable ▫Enable
DHCL Client gateway	
DHCP Client Netmask	
Start IP address	
Address Range	
Lease Time	
Name Server 1 IP	
Name Server 2 IP	
Name Server 3 IP	

4.4.7.2 DHCP fixed Host

Fixed Host IP Address list is setup via fixed command.

```
   generic             DHCP server generic parameter
>> fixed               DHCP server fixed host IP list
   relay               DHCP relay parameter
   list                Show DHCP configuration
```

You can add and delete a fixed host entry via fixed command.

```
>> add                 Add a fixed host entry
   delete              Delete a fixed host entry
```

When use the fixed host entry, you must enter the MAC address and IP address as the same

time. There can be set up to 10 maximum fixed host IP address.

DHCP Server with Fixed Host:

	Mac Address	IP Address
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

You can view the DHCP configuration via list command.

4.4.8 DNS proxy

You can setup three DNS servers on EFM modem. The number 2 and 3 DNS servers are option.

Move cursor " >> " to dns_proxy and press enter.

```
------------------------------------------------------------------------
Command: setup dns_proxy <IP> [IP] [IP]
Message: Please input the following information.

DNS server 1 (ENTER for default) <168.95.1.1>: 10.0.10.1
DNS server 2: 10.10.10.1
DNS server 3:
------------------------------------------------------------------------
```

DNS Server IP:

DNS Server 1 IP	
DNS Server 2 IP	
DNS Server 3 IP	

4.4.9 Host name

A Host Name is the unique name by which a network-attached. The hostname is used to identify a particular host in various forms of electronic communication.

Some of the ISP requires the Host Name as identification. You may check with ISP to see if your Internet service has been configured with a host name. In most cases, this field can be ignored.

Enter local host name via hostname command. Move cursor " >> " to hostname and press enter.

```
------------------------------------------------------------------------
```

Command: setup hostname <name>
Message: Please input the following information.

Local hostname (ENTER for default) <SOHO>: test

The host name can't use more than 15 characters and don't use space character.

Host Name:

Host Name	

4.4.10 Default

If you want to restore factory default, first move the cursor " >> " to default and then press enter.

Command: setup default <name>
Message: Please input the following information.

Are you sure? (Y/N): y

4.5 Status

You can view running system status of SHDSL.bis and interface via status command.

Move cursor " >> " to status and press enter.

>> shdsl.bis	**Show SHDSL.bis status**
interface	**Show interface statistics status**

Command	Description
shdsl.bis	The SHDSL.bis status includes mode, line rate, SNR margin, attenuation, and CRC error count of the local side modem, and SNR margin, attenuation and CRC error count of remote side modem. The modem can access remote side information via EOC (embedded operation channel).
interface	The statistic status of MGMT interface can be monitor by interface command.

4.5.1 Shdsl.bis

Move cursor " >> " to shdsl.bis and press enter.



The SHDSL.bis status includes mode, line rate, SNR margin, attenuation, and CRC error count of the local side modem, and SNR margin, attenuation and CRC error count of remote side modem.

4.5.2 Interface

Move cursor " >> " to interface and press enter.



4.6 Show

You can view the system information, configuration, and configuration in command script by show command.

Move cursor " >> " to show and press enter.

```
>> system          Show general information
   config          Show all configuration
   script          Show all configuration in command script
```

Command	Description
system	The general information of the system will show in system command.
config	Config command can display detail configuration information.
script	Configuration information will prompt in command script.

Move cursor " >> " to system and press enter.



4.7 Write

For any changes of configuration, you must write the new configuration to flash component using write command and then reboot the EFM modem to take affect.

Move cursor " >> " to write and press enter.

Command: write <CR>
Message: Please input the following information.

Are you sure? (y/n): y

4.8 Reboot

To reboot the EFM modem, move cursor " >> " to reboot command and press enter.

Command: reboot <CR>
Message: Please input the following information.

Do you want to reboot? (y/n): y

Type "y" can start reboot operation.

4.9 Ping

Ping command can use to diagnose basic network connectivity of EFM modem. Move move cursor to ping command and press enter.

The ping command sends an echo request packet to an address, and then awaits a reply. The ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.

Command: ping <ip> [1~65534|-t] [1~1999]
Message: Please input the following information.

IP address <IP> : 10.0.0.1
Number of ping request packets to send (TAB select): -t
Data size [1~1999]: 32

There are 3 parameters for ping command:

IP address: The IP address which you want to ping.

Number of ping request packed to send, key TAB for further selection

Default: It will send 4 packets only

1~65534: Set the number of ping request packets from 1 to 65534

-t : It will continuous until you key Ctrl+C to stop

Data Size: From 1 to 1999

4.10 Administration

You can modify the user profile, telnet access, SNMP (Sample Network Management Protocol) and supervisor information (supervisor password and ID) in admin.

For configuration the parameters, move the cursor " >> " to admin and press enter.

```
>> user          Manage user profile
   security      Setup system security
   snmp          Configure SNMP parameter
   passwd        Change supervisor password
   id            Change supervisor ID
```

4.10.1 User Profile

You can use user command to clear, modify and list the user profile. You can setup at most five users to access the EFM modem via console port or telnet in user profile table however users who have the supervisor password can change the configuration of the EFM modem. Move the cursor " >> " to user and press enter key.

```
>> clear         Clear user profile
   modify        Modify the user profile
   list          List the user profile
```

You can delete the user by number using clear command. If you do not make sure the number of user, you can use list command to check it. Modify command is to modify an old user information or add a new user to user profile.

To modify or add a new user, move the cursor " >> " to modify and press enter.

Select which profile number you want to modify.

```
---------------------------------------------------------------------
Command: admin user modify <1~5> <more...>
Message: Please input the following information.

Legal access user profile number <1~5> : 2
---------------------------------------------------------------------
```

The screen will prompt as follow.

```
>> attrib        UI mode
   profile       User name and password
```

Move the cursor ">>" to attrib and press enter.

```
---------------------------------------------------------------------
 Command: admin user modify 2 attrib <Command|Menu>
 Message: Please input the following information.
```

User interface (TAB Select) <Menu>:

There are two UI mode, command and menu mode, to setup the EFM modem.

The menu is meaning menu driven interface mode and Command is meaning line command mode. We will not discuss command mode in this manual.

Move the cursor ">>" to profile and press enter.

Command: admin user modify 2 profile <name> <pass_conf>
Message: Please input the following information.

Legal user name (ENTER for default) <test>:
Input the old Access password: **
Input the new Access password: **
Re-type Access password: ***

Input the user name and setup the new access password. The new assess password must key in two times for your confirmation.

Finally, you can use list command to check the listing of five profiles including on user name and their UI mode. On next time you re-enter this system, you can use this set of username and password. You can set up maximum to five profiles such that five sets of username and their password.

User Profile:

User profile	User name	Password	Attrib
1			▫Menu ▫Command
2			▫Menu ▫Command
3			▫Menu ▫Command
4			▫Menu ▫Command
5			▫Menu ▫Command

4.10.2 Security

Security command can be configured sixteen legal IP address for telnet access and telnet port number.

Move the cursor " >> " to security and press enter.

```
>> port          Configure telnet TCP port
   ip_pool       Legal address IP address pool
   list          Show security profile
```

4.10.2.1 Telnet TCP port

User can set up the telnet TCP port from 1 to 65534. The default port is 23.

```
--------------------------------------------------------------------------------
 Command: admin security port <1~65534>
 Message: Please input the following information.

 Telnet Listening TCP Port (ENTER for default) <23>:

 --------------------------------------------------------------------------------
```

4.10.2.2 IP address pool

For ip_pool setting, the default legal address is 0.0.0.0. (on entry number 1). It means that there is no restriction of IP to access the EFM modem via telnet.

Use modify command to setup ip_pool

```
--------------------------------------------------------------------------------
 Command: admin security ip_pool modify <1~16> <ip>
 Message: Please input the following information.

 Client address pool entry number <1~16>: 1
 Client IP address (ENTER for default) <0.0.0.0>:

 --------------------------------------------------------------------------------
```

There have sixteen address pool entry number can be setup.

Use clear command can clear legal client IP address on any pool entry number.

When move the cursor ">>" to list and press enter, you can view the full listing on security profile including the Telnet TCP port and 16 host IP address listing for your confirmation.

Telnet TCP Port:

Telnet TCP Port	

Legal client IP Address pool:

	Legal client IP Address pool
1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	

4.10.3 SNMP

Simple Network Management Protocol (SNMP) is the protocol not only governing network management, but also the monitoring of network devices and their functions.
SNMP provides for the exchange of messages between a network management client and a network management agent for remote management of network nodes. These messages contain requests to get and set variables that exist in network nodes in order to obtain statistics, set configuration parameters, and monitor network events. SNMP communications can occur over the LAN or WAN connection.
The EFM modem can generate SNMP traps to indicate alarm conditions, and it relies on SNMP community strings to implement SNMP security. This EFM Modem support MIB I & II.

Move the cursor " >> " to snmp and press enter.

```
>> community        Configure community parameter
   trap             Configure trap host parameter
```

4.10.3.1 Community

There are 5 number entries of SNMP community can be configured in this system. Move the cursor to community and press enter.

```
-------------------------------------------------------------------------
Command: admin snmp community <1~5> <more...>
Message: Please input the following information.

Community entry number <1~5> : 2
-------------------------------------------------------------------------
```

The screen will prompt as follow:

```
>> edit             Edit community entry
   list             Show community configuration
```

Move the cursor to edit and press enter.

```
-------------------------------------------------------------------------
  Command: ... 2 edit <Disable|Enable> <string> <Read_Only|Read_Write|Denied>
  Message: Please input the following information.

  Validate (TAB Select) <Enable>: Enable
  Community (ENTER for default) <private>:
  Access right (TAB Select) <Denied>:

  -------------------------------------------------------------------------
```

You can setup the following:

Validate: Set Enable or Disable.

Community: Key in the string which is serves as password for access right.

Access right: Set Read only, Read Write or Denied

Read_Only	Access read only
Read_Write	Access read and write
Denied	Deny all access

Move the cursor to list and press enter, you can view full listing on SNMP Community Pool.

5 entries of SNMP trap are allowed to be configured in this system.

SNMP Community:

SNMP entry(1~5)	
Validate	▫Enable ▫Disable
Community	
Access Right :	▫Read only ▫Read Write ▫Denied

4.10.3.2 Trap host

There have 5 entries of SNMP trap are allowed to be configured in this system. Move the cursor to trap and press enter.

```
-------------------------------------------------------------------------
Command: admin snmp trap <1~5> <more...>
Message: Please input the following information.

Trap host entry number <1~5> : 2
-------------------------------------------------------------------------
```

The screen will prompt as follow:

```
-------------------------------------------------------------------------------
>> edit                 Edit trap host parameter
   list                 Show trap configuration
-------------------------------------------------------------------------------
```

Move the cursor to edit and press enter, you can setup the following:

```
-------------------------------------------------------------------------------
 Command: admin snmp trap 1 edit <Disable|1|2> <ip> <string>
 Message: Please input the following information.

 Version (TAB Select) <Disable>:
 Trap host IP address (ENTER for default) <192.168.0.254>:
 Community (ENTER for default) <private>:

 -------------------------------------------------------------------------------
```

Version: Disable, Version 1 or Version 2

Trap host IP address: Type the trap host IP address

Community: Type the community password (string)

Move the cursor to list and press enter, you can view full listing on SNMP Trap Host Pool.

SNMP Trap Host:

Trap Host entry(1~5)	
Version	**□Disable □Ver.1 □Ver.2**
IP Address	
Community	

4.10.4 Supervisor Password and ID

The supervisor ID and password is the last door for security but the most important. Users who access the EFM modem via web browser have to use the ID and password to configure the EFM model and users who access the EFM modem via telnet or console mode have to use the password to configure the EFM modem. Suggest to change the ID and password after the first time of configuration, and then save it. At next time when you access to the EFM modem, you have to use the new password.

	ID	Password
Web Brower	●	●
Telnet/Console mode		●

4.10.4.1 Supervisor Password

Move the cursor to passwd and press enter.

```
-------------------------------------------------------------------
Command: admin passwd <pass_conf>
Message: Please input the following information.

Input old Supervisor password: ****
Input new Supervisor password: ********
Re-type Supervisor password: ********
-------------------------------------------------------------------
```

The default supervisor password is root.

4.10.4.2 Supervisor ID

Move the cursor to id and press enter.

```
-----------------------------------------------------------------------
 Command: admin id <name>
 Message: Please input the following information.

 Legal user name (ENTER for default) <root>:

 -----------------------------------------------------------------------
```

The default legal user name is root.

Supervisor ID and Password:

Supervisor ID	
Supervisor Password	

Telnet Console mode:



Web Brower mode:



4.11 Utility

There are three utility tools: upgrade, backup and restore which embedded in the firmware. You can update the new firmware via TFTP upgrade tools, backup the configuration via TFTP backup tool and restore the configuration via TFTP restore tool. For upgrade the firmware, you must have the new firmware file named *.bin which will be supported by supplier but you must have your own TFTP server. For backup and restore, you must also have your own TFTP server to backup and restore the configuration files.

Move the cursor " >> " to utility and press enter.

```
>> upgrade        Upgrade main software
   backup         Backup system configuration
   restore        Restore system configuration
```

4.11.1 Upgrade main software

Move the cursor “>>” to upgrade and press enter to upgrade firmware.

```
--------------------------------------------------------------------------------
 Command: utility upgrade <ip> <file>
 Message: Please input the following information.

 TFTP server IP address (ENTER for default) <192.168.0.2>:
 Upgrade filename (ENTER for default) <default.bin>:

 --------------------------------------------------------------------------------
```

Type TFTP server IP address and upgrade filename of the firmware.

4.11.2 Backup system configuration

Move the cursor “>>” to backup and press enter to backup system configuration.

```
 --------------------------------------------------------------------------------
 Command: utility backup <ip> <file>
 Message: Please input the following information.

 TFTP server IP address (ENTER for default) <192.168.0.2>:
 Upgrade filename (ENTER for default) <default.bin>:

 --------------------------------------------------------------------------------
```

Type TFTP server IP address and back up filename of system configuration.

4.11.3 Restore system configuration

Move the cursor “>>” to restore and press enter to restore system configuration.

```
 --------------------------------------------------------------------------------
 Command: utility restore <ip> <file>
 Message: Please input the following information.

 TFTP server IP address (ENTER for default) <192.168.0.2>:
 Upgrade filename (ENTER for default) <default.bin>:

 --------------------------------------------------------------------------------
```

Type TFTP server IP address and restore filename of system configuration.

4.12 EXIT

If you want to exit the system without saving, move the cursor " >> " to exit and press enter.

```
-------------------------------------------------------------------------------------------------------------------------
      enable                Modify command privilege
      setup                 Configure system
      status                Show running system status
      show                  View system configuration
      write                 Update flash configuration
      reboot                Reset and boot system
      ping                  Packet internet groper command
      admin                 Setup management features
      utility               TFTP upgrade utility
 >> exit                    Quit system

 -------------------------------------------------------------------------------------------------------------------------
```

```
-----------------------------------------------------------------------
 Command: exit <CR>
 Message: Please input the following information.

 Do you want to disconnect? (y/n): y
-----------------------------------------------------------------------
```

Please press "y", you can quit this system.

The screen will display:

```
-----------------------------------------------------------------
Connection closed...
Press SPACE key to enter console mode configuration!

-----------------------------------------------------------------
```

You can press SPACE key to enter this system again.

5 Appendix – Setup table

SHDSL.bis:

Mode	□STU-C □STU-R
Link type	□2-wire □4-wire □8-wire
Annex Type	□AF □BG
TCPAM	□Auto □TCPAM-16 □TCPAM-32
Max Main Rate	(3~89)
SNR Margin	(-10~21)
Line Probe	□Disable □Enable

LAN:

Link Type	□Disable □Dynamic □Static
IP Address	
Subnet mask	

DNS Server IP:

DNS Server 1 IP	
DNS Server 2 IP	
DNS Server 3 IP	

MGMT interface:

IP Address	
Subnet Mask	

DHCP Server:

DHCP Server	□Disable □Enable
DHCL Client gateway	
DHCP Client Netmask	
Start IP address	
Address Range	
Lease Time	
Name Server 1 IP	
Name Server 2 IP	
Name Server 3 IP	

DHCP Server with Fixed Host:

	Mac Address	IP Address
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

Data rate limit per port:

Port 1	LAN1	□No limit	□128K	□256K	□512K	□1M	□2M
Port 2	LAN2	□No limit	□128K	□256K	□512K	□1M	□2M
Port 3	LAN3	□No limit	□128K	□256K	□512K	□1M	□2M
Port 4	LAN4	□No limit	□128K	□256K	□512K	□1M	□2M
Port 5	DSL	□No limit	□128K	□256K	□512K	□1M	□2M
Port 6	Sniffing	□No limit	□128K	□256K	□512K	□1M	□2M

VLAN Mode:

VLAN Mode	□Disable □802.1Q Tag VLAN □Port Based VLAN

802.11Q VLAN:

		1	2	3	4	5	6
No.	VID	LAN1	LAN2	LAN3	LAN4	DSL	Sniffing
1							
2							
3							
4							
5							
6							
7							
8							
PVID							
Link Type		□Access □Trunk	□Access □Trunk	□Access □Trunk	□Access □Trunk	□Access □Trunk	□Access □Trunk

Port Based VLAN:

No.	LAN1	LAN2	LAN3	LAN4	DSL	Sniffing
1						
2						
3						
4						
5						
6						
7						
8						

QoS Mode:

QoS Mode	□Disable □Port Based □VLAN Tag □IP DSCP

Queue Weight:

Queue Index	0	1	2	3
Weight Value				

Queue Schedule:

Queue Schedule	□Type 1 □Type 2

Port Based Priority QoS:

Port	1(LAN1)	2(LAN2)	3(LAN3)	4(LAN4)	5(DSL)	6(Sniffing)
Queue Index						

VLAN Tag Priority QoS:

VLAN Tag Index	0	1	2	3	4	5	6	7
Queue Index								

IP DSCP QoS:

DSCP	Queue Index	DSCP	Queue Index	DSCP	Queue Index	DSCP	Queue Index
0		16		32		48	
1		17		33		49	
2		18		34		50	
3		19		35		51	
4		20		36		52	
5		21		37		53	
6		22		38		54	
7		23		39		55	
8		24		40		56	
9		25		41		57	
10		26		42		58	
11		27		43		59	
12		28		44		60	
13		29		45		61	
14		30		46		62	
15		31		47		63	

User Profile:

User profile	User name	Password	Attrib
1			☐Menu ☐Command
2			☐Menu ☐Command
3			☐Menu ☐Command
4			☐Menu ☐Command
5			☐Menu ☐Command

Telnet TCP Port:

Telnet TCP Port	

Legal client IP Address pool:

	Legal client IP Address pool
1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	

Supervisor ID and Password:

Supervisor ID	
Supervisor Password	

Host Name:

Host Name	

SNMP Community:

SNMP entry (1)	
Validate	□Enable □Disable
Community	
Access Right :	□Read only □Read Write □Denied

SNMP entry (2)	
Validate	□Enable □Disable
Community	
Access Right :	□Read only □Read Write □Denied

SNMP entry (3)	
Validate	□Enable □Disable
Community	
Access Right :	□Read only □Read Write □Denied

SNMP entry (4)	
Validate	□Enable □Disable
Community	
Access Right :	□Read only □Read Write □Denied

SNMP entry (5)	
Validate	□Enable □Disable
Community	
Access Right :	□Read only □Read Write □Denied

SNMP Trap Host:

Trap Host entry (1)	
Version	□Disable □Ver.1 □Ver.2
IP Address	
Community	

Trap Host entry (2)	
Version	□Disable □Ver.1 □Ver.2
IP Address	
Community	

Trap Host entry (3)	
Version	□Disable □Ver.1 □Ver.2
IP Address	
Community	

Trap Host entry (4)	
Version	□Disable □Ver.1 □Ver.2
IP Address	
Community	

Trap Host entry (5)	
Version	□Disable □Ver.1 □Ver.2
IP Address	
Community	